



Stair Treads, Nosing and Cleats Installation Guide

Product Overview

Stair Treads, Nosing and Cleats are designed to provide a grip surface, in turn reducing the risk of trips, slips and falls.

Installation

The range comes with pre-drilled holes to allow you to fix these over steel plating, chequered plates, metal grills, on concrete or on wood. Please note that fixings are not provided with the product.

Prior to installation, we recommend ensuring that the area is clean and dry.

Installation on Steel Plates and Chequered Plates:

Use M6 countersunk self-drilling Tek screws or M6 countersunk screw washer and Nyloc nut assemblies.

Installation on Metal grills:

Use galvanised or stainless steel universal saddle clamps with M6 stainless countersunk socket screws and Nyloc locking nuts.

Installation on Masonry:

Use M6 stainless countersunk concrete anchors or M6 countersunk self-securing concrete anchors.

Installation on Wood:

Use 12 gauge self-tapping countersunk wood screws.

Maintenance

Minimal maintenance is required.

To clean, simply wash with a hose or hot / cold water pressure using usual detergents or degreasers. Heavy dirt can be brushed away with a stiff broom or handbrush.

Wash off excess cleaning fluids with clean water.

Please do not use wire brushes or scrapers on the item.

Warranty

The supplier provided a 1 year warranty against ramp defects from the original purchase date. Please note that the warranty will be void if used outside of the recommended guidance. If you wish to undertake a warranty claim please contact us and provide details of the fault and images via email at hello@therampfactory.co.uk. The Ramp Factory are not responsible for incidental or consequential damages.

Contact Details

Thank you for choosing The Ramp Factory If you have any questions, please contact us.

Email: hello@therampfactory.co.uk

Telephone (UK): 01372 648587

Address: Unit 5 Quantum Business Park, Beacon Hill Road, Church Crookham, Fleet GU52 8EA